

Operation instruction • english  
Gebrauchsanweisung • deutsch  
Gebruiksaanwijzing • nederlands  
Manuel d'utilisation • français

1905300E  
0647

# FASTMIG™

KMS 300

KMS 400

KMS 500



---

# CONTENTS

|  |    |
|--|----|
| <b>1. PREFACE</b> .....  | 3  |
| 1.1. INTRODUCTION.....   | 3  |
| 1.2. PRODUCT INTRODUCTION.....   | 3  |
| 1.2.1. OPERATION CONTROL AND CONNECTORS.....                               | 3  |
| 1.3. ACCESSORIES.....  | 4  |
| 1.3.1. REMOTE CONTROL DEVICES.....   | 4  |
| 1.3.2. CABLES.....   | 4  |
| 1.4. OPERATION SAFETY.....   | 5  |
| <b>2. INSTALLATION</b> .....   | 6  |
| 2.1. SITING THE MACHINE.....   | 6  |
| 2.2. CONNECTION TO THE MAINS SUPPLY.....                                   | 6  |
| 2.3. WELDING AND EARTH CABLES.....   | 7  |
| <b>3. OPERATION CONTROL SWITCHES AND POTENTIOMETERS AND THEIR USE</b> .... | 7  |
| 3.1. MAIN SWITCH I/O.....  | 7  |
| 3.2. PILOT LAMPS.....  | 7  |
| 3.3. OPERATION OF COOLING FAN.....   | 8  |
| <b>4. MANUAL METAL ARC WELDING</b> .....                                   | 8  |
| <b>5. MAINTENANCE</b> .....  | 8  |
| 5.1. CABLES.....   | 8  |
| 5.2. POWER SOURCE.....   | 8  |
| 5.3. REGULAR MAINTENANCE.....  | 8  |
| <b>6. OPERATION DISTURBANCES</b> .....                                     | 9  |
| 6.1. OPERATION OF THE OVERLOAD PROTECTION.....                             | 9  |
| 6.2. CONTROL FUSES.....  | 9  |
| 6.3. UNDER- AND OVERVOLTAGES IN THE MAINS SUPPLY.....                      | 9  |
| 6.4. LOSS OF A PHASE IN THE MAINS SUPPLY.....                              | 9  |
| <b>7. DISPOSAL OF THE MACHINE</b> .....                                    | 9  |
| <b>8. ORDERING NUMBERS</b> .....   | 10 |
| <b>9. TECHNICAL DATA</b> .....   | 11 |
| <b>10. TERMS OF GUARANTEE</b> .....  | 12 |


# 1. PREFACE

## 1.1. INTRODUCTION

Congratulations on having purchased this product. Properly installed Kemppi products should prove to be productive machines requiring maintenance at only regular intervals.

This manual is arranged to give you a good understanding of the FastMig™ equipment and its safe operation. It also contains maintenance information and technical specifications. Read this manual from front to back before installing, operating or maintaining the equipment for the first time. For further information on Kemppi products please contact us or your nearest Kemppi distributor.

The specifications and designs presented in this manual are subject to change without prior notice.

In this document, for danger to life or injury the following symbol is used: 

Read the warning texts carefully and follow the instructions. Please also study the Operation safety instructions and respect them when installing, operating and servicing the machine.

## 1.2. PRODUCT INTRODUCTION

FastMig™ KMS 300, 400 and 500 are multi-operator power sources designed for demanding professional use. They are suitable for MMA and MIG welding in DC.

### 1.2.1. Operation control and connectors


|      |                                       |               |
|------|---------------------------------------|---------------|
| F11  | Fuse for connection for control table | 6,3 A delayed |
| H11  | Signal lamp                           | I/O           |
| H12  | Warning lamp for thermal protection   |               |
| S11  | Main switch                           | I/O           |
| X11, | Welding connection                    | parallel      |
| X13  | Welding connection                    |               |
| X12  | Earth connection                      |               |
| X14, | Connection for control cable          | parallel      |
| X15  | Connection for control cable          |               |
| 01   | Inlet of mains cable                  |               |



## 1.3. ACCESSORIES


### 1.3.1. Remote control devices

#### R10



#### R20


Wire feed adjustment,  
electrode current adjustment



MIG-MAG remote control device with controls for wire feed and voltage, memory scales 1 ... 5.  
You can use control device also for control of MMA current.

### 1.3.2. Cables

#### FastMig™ KMS 300, FastMig™ KMS 400, FastMig™ KMS 500



- 16d Extension cable for remote control
- 20 Earth cable
- 21 MMA welding cable
- R10, R20 Remote control devices

---

## 1.4. OPERATION SAFETY

Please study these Operation safety instructions and respect them when installing, operating and servicing the machine.

### ***Welding arc and spatters***

Welding arc hurts unprotected eyes. Be careful also with reflecting arc flash. Welding arc and spatter burn unprotected skin. Use safety gloves and protective clothing.

### ***Danger for fire or explosion***

Pay attention to fire safety regulations. Remove flammable or explosive materials from welding place. Always ensure that you have sufficient fire fighting equipment available where you are welding. Be prepared for hazards in special welding jobs, eg. for the danger of fire or explosion when welding container type work pieces. Note! Fire can break out from sparks even several hours after the welding work has been finished!

### ***Mains voltage***

Never take welding machine inside a work piece (eg. container or truck). Do not place welding machine on a wet surface. Always check cables before operating the machine. Change damaged cables without delay. Damaged cables may cause an injury or set out a fire. Connection cable must not be crushed, it must not touch sharp edges or hot work pieces.

### ***Welding power circuit***

Isolate yourself by using proper protective clothing, do not wear wet clothing. Never work on a wet surface or use defect cables. Do not put the MIG-gun or welding cables on welding machine or on other electric equipment. Do not press the MIG-gun switch, if the gun is not directed towards a work piece.

### ***Welding fumes***

Take care that there is sufficient ventilation during welding. Take special safety precautions when welding metal, which contain lead, cadmium, zinc, mercury or beryllium.




**This equipment's electromagnetic compatibility (EMC) is designed for use in an industrial environment. Class A equipment is not intended for use in residential location where the electrical power is provided by the public low-voltage supply system.**

## 2. INSTALLATION

### 2.1. SITING THE MACHINE

**⚠** Site the machine on a stationary, horizontal, dry base in a position that does NOT allow dust, dirt or metal particles to enter the machine's cooling air flow.



- Preferably site the machine somewhat higher above the floor level.
- Ensure that the front as well as the rear of the machine there is at least 20 cm free distance to allow good circulation of the cooling air through the machine.
- Protect the machine against heavy rain and in hot circumstances against direct sunshine. Ensure the free circulation of the cooling air.

**⚠** Degree of protection of machine IP23C allows at its maximum the water spray coming in 60° angle to hit machine's outer covering.

See to that the machine is positioned away from the line of particle spray, created by grinding tools etc.

### 2.2. CONNECTION TO THE MAINS SUPPLY

FastMig™ power sources are delivered equipped with 5 m mains cable without plug.


If local electricity regulations of operating country are stating otherwise, the mains cable should be replaced in conformity with the local regulations.

Connection of the mains cable, mounting and change of the plug should only be carried out by a competent electrician.


Remove the machine's right side plate to enable the mounting of a mains cable.

KMS power sources can be connected to the mains supply of 400 V 3~.

***If changing the mains cable take into consideration the following:***

The cable is entered into the machine through the inlet ring on the rear panel of the machine and fastened with a cable clamp (05). The phase conductors of the cable are coupled to connectors L1, L2 and L3. The earth protection coloured green-yellow is coupled to connector. 

**⚠** If you are using 5-lead cable, do not connect neutral conductor.



Sizes of the mains cables and fuse ratings for the machine at 100 % duty cycle are specified in the table below:

|                | Rated voltage | Mains voltage range | Fuses, slow-blow | Connection cable *) mm <sup>2</sup> |
|----------------|---------------|---------------------|------------------|-------------------------------------|
| <b>KMS 300</b> | 400 V 3~      | 360 V... 440 V      | 20 A             | 4 x 6.0 S                           |
| <b>KMS 400</b> | 400 V 3~      | 360 V... 440 V      | 25 A             | 4 x 6.0 S                           |
| <b>KMS 500</b> | 400 V 3~      | 360 V... 440 V      | 35 A             | 4 x 6.0 S                           |

\*) In cables of S type there is a protective grounding conductor coloured green-yellow.

## 2.3. WELDING AND EARTH CABLES

Recommended copper cables with cross-sectional area are as follows:

FastMig™ KMS 300 50 ... 70 mm<sup>2</sup>

FastMig™ KMS 400 70 ... 90 mm<sup>2</sup>

FastMig™ KMS 500 70 ... 90 mm<sup>2</sup>

In enclosed table are shown typical load capacities of rubber insulated copper cables, when ambient temperature is 25 °C and lead temperature is 85 °C.

| Cable                    | Duty cycle ED |       |       | Voltage loss / 10 m |
|--------------------------|---------------|-------|-------|---------------------|
|                          | 100 %         | 60 %  | 30 %  |                     |
| <b>50 mm<sup>2</sup></b> | 285 A         | 370 A | 520 A | 0,35 V / 100 A      |
| <b>70 mm<sup>2</sup></b> | 355 A         | 460 A | 650 A | 0,25 V / 100 A      |
| <b>95 mm<sup>2</sup></b> | 430 A         | 560 A | 790 A | 0,18 V / 100 A      |

Do not overload welding cables due to voltage losses and heating.


Fasten the earth clamp of the return current cable carefully, preferably direct onto the piece to be welded. The contact surface of the earth clamp should always be as large as possible.

Clean the fastening surface from paint and rust.

## 3. OPERATION CONTROL SWITCHES AND POTENTIOMETERS AND THEIR USE

### 3.1. MAIN SWITCH I/O

When you turn the switch into I-position, pilot lamp H11 on the front face is illuminated and the machine is ready for use.

 **Always turn the machine on and off with the mains switch, never use the mains plugs as a switch.**

### 3.2. PILOT LAMPS

The pilot lamps of the machine report the electric operation:

The green pilot lamp H11 when lit indicates that the machine is on and ready for use and it is connected to the mains supply with the main switch in the I-position.

H12 indicates when lit that the thermal protection of the machine has been activated due to over heating. The cooling fan will continue to run and cool the machine down and when the lamp is off the machine is ready to weld.

---

### 3.3. OPERATION OF COOLING FAN

In FastMig™ -power sources there are two simultaneously operating fans.

- The fan is started for a moment when main switch is placed into position I.
- The fan will start during welding as the machine heats up and it will run for 1 to 10 minutes after the welding has stopped.

## 4. MANUAL METAL ARC WELDING

The FastMig™ power source can be used in electrode welding by connecting a FastMig™ MFS 53, MFS 55 wire feeder to it. The power source can be made suitable for electrode welding without a wire feeder by connecting an R10 or R20 remote control to the X14 or X15 terminal at the back of the power source for welding current adjustment, and the welding power cable connected to the power source's (+) connector X11 or X12.

## 5. MAINTENANCE

The amount of use and the working environment should be taken into consideration when planning the frequency of maintenance of the machine. Careful use and preventive maintenance will help to ensure trouble-free operation.

### 5.1. CABLES

Check the condition of welding and connection cables daily. Do not use damaged cables.

Make sure that the mains cables in use are safe and according to laid down regulations.

The repair and mounting of a mains connection cable should be carried out only by an authorised electrician.

### 5.2. POWER SOURCE



**Note! Disconnect the plug of the machine from the mains socket and wait approx. 2 minutes (capacitor charge) before removing the cover plate.**

Check at least every half year:

- Electric connectors of the machine - clean the oxidised parts and tighten the loosened ones.
- Note! You must know correction tension torques before starting the reparation of the joints.
- Clean the inner parts of the machine from dust and dirt e.g. with a soft brush and vacuum cleaner. Also clean the ventilation net behind the front grate.
- Do not use compressed air, there is a risk that dirt is packed even more tightly into gaps of cooling profiles.
- Do not use pressure washing device.
- Only authorised electrician shall carry out repairs to the machines.

### 5.3. REGULAR MAINTENANCE

Kemppi Service Workshops make regular maintenance according to agreement.

**The major points in the maintenance procedure are listed as follows:**

- Cleaning of the machine
- Checking and maintenance of the welding tools
- Checking of connectors, switches and potentiometers
- Checking of electric connections
- Checking of mains cable and plug
- Damaged parts or parts in bad connection are replaced by new ones
- Maintenance testing. Operation and performance values of the machine are checked, and adjusted when necessary by means of test equipment.

---

## 6. OPERATION DISTURBANCES

In case of problems contact the Kemppi works in Lahti, Finland, or your local Kemppi dealer. Check the maintenance objects before the machine is sent to the Service Workshop.

### 6.1. OPERATION OF THE OVERLOAD PROTECTION

Yellow pilot lamp H12 of thermal protection is lit when thermostat has operated due to overheating of machine.

The thermostat of machine will operate, if machine is continuously loaded over rated values or cooling air circulation is blocked.

Cooling fan cools down the machine and when the pilot lamp is not lit the machine is automatically ready for welding.

### 6.2. CONTROL FUSES

Fuse F11, 6,3 A delayed, on the rear wall of machine is as protection for connection of auxiliary devices X14-15.



**Use same type and rating of fuse which is marked beside the fuse adapter. Damage caused by a wrong type fuse is not covered by the guarantee.**

### 6.3. UNDER- AND OVERVOLTAGES IN THE MAINS SUPPLY

Primary circuits of machine are protected against sudden, transient overvoltages.

Machine is designed to withstand 3 x 440 V voltage continuously (see technical data). See to it that voltage is kept within admissible limits especially when mains supply is taken e.g. from combustion engine generator.

If the mains has undervoltage (under approx. 300 V) or overvoltage (over approx. 480 V) machine control stops to operate automatically.

### 6.4. LOSS OF A PHASE IN THE MAINS SUPPLY

Loss of a phase causes noticeable poorer welding properties than normally or the machine doesn't get started at all. Loss of a phase can be due to following:

- blowing of mains supply fuse
- defective mains cable
- bad connection of mains connection cable on terminal block or plug of machine

## 7. DISPOSAL OF THE MACHINE



Do not dispose of electrical equipment together with normal waste!

In observance of European Directive 2002/96/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical equipment that has reached the end of its life must be collected separately and returned to an environmentally compatible recycling facility. As the owner of the equipment, you should get information on approved collection systems from our local representative.

By applying this European Directive you will improve the environment and human health!

---

## 8. ORDERING NUMBERS

|   |                         |           |
|---|-------------------------|-----------|
| FastMig™ KMS 300                        |                         | 6053000   |
| FastMig™ KMS 400                        |                         | 6054000   |
| FastMig™ KMS 500                        |                         | 6055000   |
| SF 51                                   | 200 mm, LED             | 6085100   |
| SF 52                                   | 200 mm, LED             | 6085200   |
| SF 53                                   | 300 mm, LED             | 6085300   |
| SF 54                                   | 300 mm, LED             | 6085400   |
| Return current cable                    | 5 m, 50 mm <sup>2</sup> | 6184511   |
| Return current cable                    | 5 m, 70 mm <sup>2</sup> | 6184711   |
| Cable for MMA welding                   | 5 m, 50 mm <sup>2</sup> | 6184501   |
| Cable for MMA welding                   | 5 m, 70 mm <sup>2</sup> | 6184701   |
| R10                                     |                         | 6185409   |
| Remote controlled interconnecting cable | 10 m                    | 6185481   |
| Cooling unit Fastcool 10                |                         | 606810001 |
| Transport unit PM 500                   |                         | 6185291   |
| Gun holder GH 30                        |                         | 6256030   |

## 9. TECHNICAL DATA

|   | FastMig™ KMS 300     | FastMig™ KMS 400     | FastMig™ KMS 500     |
|---|----------------------|----------------------|----------------------|
| <b>Mains voltage 3~50/60 Hz</b>             |                      |                      |                      |
|   | 400 V -15 %...+20 %  | 400 V -15 %...+20 %  | 400 V -15 %...+20 %  |
| <b>Rated power</b>                          |                      |                      |                      |
| 60 ED                                       | -                    | -                    | 26,1 kVA             |
| 80 % ED                                     | -                    | 19,5 kVA             | -                    |
| 100 % ED                                    | 13,9 kVA             | 18,5 kVA             | 20,3 kVA             |
| <b>Connection cable/fuse delayed</b>        |                      |                      |                      |
|   | 4 x 6 S - 5 m / 25 A | 4 x 6 S - 5 m / 35 A | 4 x 6 S - 5 m / 35 A |
| <b>Loadability 40 °C</b>                    |                      |                      |                      |
| 60 % ED                                     | -                    | -                    | 500 A                |
| 80 % ED                                     | -                    | 400 A                | -                    |
| 100 % ED                                    | 300 A                | 380 A                | 430 A                |
| <b>Welding current and voltage range</b>    |                      |                      |                      |
| MMA   | 10 A ... 300 A       | 10 A ... 400 A       | 10 A ... 500 A       |
| MIG   | 10 V ... 37 V        | 10 V ... 39 V        | 10 V ... 42 V        |
| <b>Max. welding voltage</b>                 |                      |                      |                      |
|   | 46 V                 | 46 V                 | 46 V                 |
| <b>Open circuit voltage</b>                 |                      |                      |                      |
|   | 50 V                 | 50 V                 | 50 V                 |
| <b>Open circuit power</b>                   |                      |                      |                      |
|   | 25 W                 | 25 W                 | 25 W                 |
| <b>Efficiency</b>                           |                      |                      |                      |
|   | 87 %                 | 87 %                 | 87 %                 |
| <b>Power factor</b>                         |                      |                      |                      |
|   | 0,9                  | 0,9                  | 0,9                  |
| <b>Storage temperature range</b>            |                      |                      |                      |
|   | -40 ... +60 °C       | -40 ... +60 °C       | -40 ... +60 °C       |
| <b>Operating temperature range</b>          |                      |                      |                      |
|   | -20 ... +40 °C       | -20 ... +40 °C       | -20 ... +40 °C       |
| <b>Degree of protection</b>                 |                      |                      |                      |
|   | IP 23 C              | IP 23 C              | IP 23 C              |
| <b>External dimensions</b>                  |                      |                      |                      |
| length                                      | 590 mm               | 590 mm               | 590 mm               |
| width                                       | 230 mm               | 230 mm               | 230 mm               |
| height                                      | 430 mm               | 430 mm               | 430 mm               |
| <b>Weight</b>                               | 34 kg                | 35 kg                | 36 kg                |
| <b>Voltage supply for auxiliary devices</b> |                      |                      |                      |
|   | 50 V DC              | 50 V DC              | 50 V DC              |
| X14, X15                                    | fuse 6,3 A delayed   | fuse 6,3 A delayed   | fuse 6,3 A delayed   |
| <b>Voltage supply for cooling unit</b>      |                      |                      |                      |
|   | 1~, 400 V / 250 VA   | 1~, 400 V / 250 VA   | 1~, 400 V / 250 VA   |

---

## 10. TERMS OF GUARANTEE

Kemppi Oy provides a guarantee for products manufactured and sold by them if defects in manufacture and materials occur. Guarantee repairs must be carried out only by an Authorised Kemppi Service Agent. Packing, freight and insurance costs to be paid by orderer. The guarantee is effected on the date of purchase. Verbal promises which do not comply with the terms of guarantee are not binding on guarantor.

### ***Limitations on guarantee***

The following conditions are not covered under the terms of guarantee: defects due to natural wear and tear, non-compliance with operating and maintenance instructions, connection to incorrect or faulty supply voltage (including voltage surges outside equipment spec.), incorrect gas pressure, overloading, transport or storage damage, fire or damage due to natural causes i.e. lightning or flooding.

This guarantee does not cover direct or indirect travelling costs, daily allowances or accommodation.

Note: Under the terms of guarantee, welding torches and their consumables, feeder drive rolls and feeder guide tubes are not covered. Direct or indirect damage due to a defective product is not covered under the guarantee. The guarantee is void if changes are made to the product without approval of the manufacturer, or if repairs are carried out using non-approved spare parts.

The guarantee is also void if repairs are carried out by non-authorized agents.

### ***Undertaking guarantee repairs***

Guarantee defects must be informed to Kemppi or authorised Kemppi Service Agents within the guarantee period. Before any guarantee work is undertaken, the customer must provide proof of guarantee or proof of purchase, and serial number of the equipment in order to validate the guarantee.

The parts replaced under the terms of guarantee remain the property of Kemppi.

Following the guarantee repair, the guarantee of the machine or equipment, repaired or replaced, will be continued to the end of the original guarantee period.

KEMPPI OY  
PL 13  
FIN – 15801 LAHTI  
FINLAND  
Tel (03) 899 11  
Telefax (03) 899 428  
www.kemppi.com

KEMPPIKONEET OY  
PL 13  
FIN – 15801 LAHTI  
FINLAND  
Tel (03) 899 11  
Telefax (03) 7348 398  
e-mail: myynti.fi@kemppi.com

KEMPPI SVERIGE AB  
Box 717  
S – 194 27 UPPLANDS VÄSBY  
SVERIGE  
Tel (08) 590 783 00  
Telefax (08) 590 823 94  
e-mail: sales.se@kemppi.com

KEMPPI NORGE A/S  
Postboks 2151, Postterminalen  
N – 3103 TØNSBERG  
NORGE  
Tel 33 34 60 00  
Telefax 33 34 60 10  
e-mail: sales.no@kemppi.com

KEMPPI DANMARK A/S  
Literbuen 11  
DK – 2740 SKOVLUNDE  
DANMARK  
Tel 44 941 677  
Telefax 44 941 536  
e-mail:sales.dk@kemppi.com

KEMPPI BENELUX B.V.  
Postbus 5603  
NL – 4801 EA BREDA  
NEDERLAND  
Tel +31 (0)76-5717750  
Telefax +31 (0)76-5716345  
e-mail: sales.nl@kemppi.com

KEMPPI (UK) Ltd  
Martti Kemppi Building  
Fraser Road  
Priory Business Park  
BEDFORD, MK443WH  
ENGLAND  
Tel 0845 6444201  
Fax 0845 6444202  
e-mail: sales.uk@kemppi.com

KEMPPI FRANCE S.A.  
65 Avenue de la Couronne des Prés  
78681 EPONE CEDEX  
FRANCE  
Tel (01) 30 90 04 40  
Telefax (01) 30 90 04 45  
e-mail: sales.fr@kemppi.com

KEMPPI GmbH  
Otto – Hahn – Straße 14  
D – 35510 BUTZBACH  
DEUTSCHLAND  
Tel (06033) 88 020  
Telefax (06033) 72 528  
e-mail:sales.de@kemppi.com

KEMPPI SP. z o.o.  
Ul. Piłsudskiego 2  
05-091 ZĄBKI  
Poland  
Tel +48 22 781 6162  
Telefax +48 22 781 6505  
e-mail: info.pl@kemppi.com

KEMPPI WELDING  
MACHINES AUSTRALIA PTY LTD  
P.O. Box 404 (2/58 Lancaster Street)  
Ingleburn NSW 2565, Australia  
Tel. +61-2-9605 9500  
Telefax +61-2-9605 5999  
e-mail: info.au@kemppi.com

ООО КЕМППИ  
127018 Moscow, Polkovaya str. 1,  
Building 6  
e-mail: info.ru@kemppi.com

ООО КЕМППИ  
127018 Москва, ул. Полковная 1,  
строение 6